Analysis of Gas Line Antifreeze, Windshield Washer Fluid, and Ethylene Glycol Antifreeze

By Lester Hankin

A cooperative study by The Connecticut Agricultural Experiment Station, New Haven and the Product Safety Division of the Connecticut Department of Consumer Protection, Hartford.



By Lester Hankin

Antifreeze materials are added to protect water from freezing in vehicle gasoline tanks, in reservoirs of windshield washer fluid, and in vehicle radiators.

In gasoline tanks, gas line antifreeze products containing the active ingredients methyl alcohol or isopropyl alcohol are used. The alcohol mixes with traces of water and prevents the water from freezing in the gasoline tank or in gasoline lines.

In windshield washer fluids, methyl alcohol is commonly used. Manufacturers usually do not declare a percentage of alcohol, but labels generally state that the product will protect from freezing down to -20 or -25F. According to published freezing point values (1) a mixture of 33% methyl alcohol and 67% water will not freeze above -20F. These products also may contain a cleaning agent or other ingredients that help lower the freezing point.

Ethylene glycol antifreeze is used in vehicle radiators. Manufacturers recommend using at least a mixture of 50% ethylene glycol and 50% water. The labels state that the mixture will protect from freezing down to -25F.

There are no standards for the amount and type of active ingredients used in these three types of products. All products were tested by analyzing for type and percentage of active ingredient and determining if they met their label claims. If the freezing point stated on the label was inconsistent with the alcohol content (1) a freezing point determination was made.

Connecticut Statutes require that products containing methyl alcohol show a warning statement on the label (2).

In this study we examined 19 gas line antifreeze products, 13 windshield washer fluids, and six ethylene glycol antifreeze products.

Methods

Samples were collected by an inspector of the Connecticut Department of Consumer Protection and analyzed at The Connecticut Agricultural Experiment Station. Analyses for alcohols and ethylene glycol were by gas chromatography. A Varian Model 920 with a thermal conductivity detector and a Poropak Q stainless steel column was used. The temperature of the column was 150C and of the injection port was 170C. The nitrogen carrier gas flowed at a rate of 40 milliliters per minute. Freezing points were determined by cooling the sample with liquid nitrogen and observing freezing.

Results

The brands of the 19 gas line antifreeze products tested and the type and percentage of alcohol found are in Table 1. Fourteen contained only methyl alcohol, four only isopropyl alcohol, and one a mixture of methyl alcohol and isopropyl alcohol. All products contained essentially all active ingredient and were labeled correctly.

The brands of the 13 windshield washer fluids and the type and percentage of alcohol found are in Table 2. All samples stated on the label that they would protect from freezing to -20 or -25F, i.e., would not freeze at a temperature above -20 or -25F. Based on actual alcohol content and published freezing point values, sample numbers 1, 3, 11, and 12 would freeze above -20F. Actual freezing point determinations, however, showed these four products did not freeze above -20F. The addition of cleaning materials or other substances probably depressed the freezing point sufficiently to justify the label claim that they would not freeze above -20F.

Sample number 8 correctly declared on the label that it contained 35% methyl alcohol. Sample number 5 contained 100% methyl alcohol, and the label on this product states that below 0F a 50% mixture in water should be used. We calculated that such a mixture would prevent freezing at least to -36F.

The six brands of ethylene glycol antifreeze and the percentage of ethylene glycol found are in Table 3. All contained at least 95% ethylene glycol. Calculations show that a 50% solution of all six products in water would not freeze above -30F. Thus the label claims that they would not freeze above -30F are correct.

Conclusions

All 19 gas line antifreeze products contained either methyl alcohol or isopropyl alcohol or both and were labeled correctly. The label claims for 13 windshield washer fluids that they would not freeze above a stated temperature were correct. The label claims for six ethylene glycol radiator antifreeze products also were correct.

Acknowledgments

Analyses were by Vipin Agarwal and Sunrae McLean. Samples were collected by Mark Giulietti under the direction of Lois Bryant, Chief, Product Safety Division, Connecticut Department of Consumer Protection.

References

- Handbook of Chemistry and Physics, 61st edition, 1980-1981. CRC Press, Boca Raton, FL.
- General Statutes of Connecticut revised to January 1, 1985, section 21a-335(e)(C).

Table 1. Alcohol Content of Gas Line Antifreeze.

Sample Number	Brand	% Alcohol & Typ
1	BG gas line antifreeze & dryer	98 - Isopropyl
1 2 3 4 5 6 7	Caldor 100% gas line antifreeze	98 - Methyl
3	Cristy dry gas	99 - Methyl
4	Auto Value gas line antifreeze	99 - Methy1
5	Berkebile 2 + 2 gas line antifreeze	
6	Crown gas line dryer antifreeze	98 - Methyl
	Master gas line antifreeze	99 - Methyl
8	Monarch gas line antifreeze	99 - Methyl
9	NAPA Mac's fuel system treatment	65 - Methyl &
	23 may 2 1 1 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	35 - Isopropy1
10	NAPA Mac's thermo-aid	100 - Isopropy1
11	PAHNOL gas line antifreeze &	
	gas tank dryer	97 - Methyl
12	Penn-Pride gas line antifreeze	98 - Methy1
13	Prestone gas dryer & gas line	SAN SECONOMIN
	antifreeze	99 - Methyl
14	Q7 gas line antifreeze	99 - Isopropyl
15	Rickel gas line antifreeze	97 - Methyl
16	Savo gas line antifreeze	97 - Methyl
17	Shell gas line antifreeze dryer	99 - Methy1
18	Sure-Thaw gasoline antifreeze	50.00 (0.000 m)
	& dryer	97 - Methy1
19	Uni-Guard Ice-O-Dry	98 - Isopropyl

Table 2. Alcohol Content of Windshield Washer Fluids.

Sample Number	Brand	% A1	col	hol & Type	Claimed Protection	To
1	Caldor windshield washer antifreeze	30	_	Methyl	-20F	_
2	CVS windshield washer & solvent	37	-	Methy1	-20F	
3	Crown windshield washer fluid			Methyl	-25F	
4	Kleen-Bright windshield washer antifreeze			Methyl.	-25F	
5	NAPA windshield washer solvent			Methy1 ^b	c	
2 3 4 5 6	Our Own summer/winter windshield wash					
	(Bradlees)	38	T_{i}	Methy1	-25F	
7	PAHNOL windshield washer antifreeze					
	cleaner	37	-	Methyl	-20F	
8	Pathmark antifreeze windshield washer	40	-	Methy1	-25F	
9	Prestone windshield washer antifreeze/			100 A		
	cleaner	35	_	Methy1	-20F	
10	Rickel windshield washer	36	-	Methy1	-20F	
11	Serv-U windshield washer	30	-	Methy1	-20F	
12	Uni-Guard windshield washer antifreeze			Methy1	-20F	
13	UNIFIDE windshield washer fluid			Methyl	-20F	

Table 3. Ethylene Glycol Content of Radiator Antifreeze.

Sample Number	Brand	% Ethylene Glycol		
1	Autovalue antifreeze coolant	96		
2	Conoco antifreeze/coolant	95		
3	NAPA antifreeze/coolant	95		
4	Quaker State antifreeze coolant	95		
5	Texaco antifreeze coolant	95		
6	Zerex antifreeze/coolant (Conoco)	95		

a. All met their claims.b. This product is to be diluted with water before use.c. No claim.